



FIX STUDS TO BATHROOM FLANGES LIKE THIS.



FIX STUDS TO BATHROOM WALL PANELS BETWEEN FLANGES LIKE THIS.

SHOWS TYPICAL UNDER FLOOR CHASSIS SET OUT. THIS IS ON AN FP1000.

